




NERM 1000

WIRING CONNECTION DIAGRAM



Contacts are shown in the NO AUX SUPPLY and/or TRIP present condition.
SEE NOTE



NOTE:

THE NERM 1000 IS A FAIL SAFE RELAY (contacts will be in TRIP condition if no power present)
DIAGRAM CONTACTS ARE SHOWN IN A NO AUX SUPPLY and/or TRIPPED CONDITION.

The NERM 1000 has been designed to TRIP should the resistance of the neutral earthing resistor (NER) exceed 150% of its specified value or alternatively go open circuit.